

Quick Installation Guide

150Mbps Wireless N USB Adapter

MODEL NO. TL-WN727N



Package Contents




TL-WN727N



QIG



USB Cable



Resource CD


System Requirement

- Windows 8
- Windows 7
- Windows XP

2 Software Installation

(The installation procedures in Windows 8/ 7/ XP are similar. Here we use the procedures in Windows 7 as an example.)

1 Insert the TP-LINK resource CD into the CD-ROM drive.




2 Find the model TL-WN727N and select **Install Driver&Utility**.




3 The **InstallShield Wizard** window will appear. Click **Next** to continue.




4 Select **Install TP-LINK Wireless Configuration Utility and Driver** and then click **Next**.




5 Click **Change** to specify the destination location or you can leave it default. Click **Next** to continue.




6 Click **Install** to install the driver and utility for your adapter.



7 The installation of the driver and utility may take 1~2 minutes.




8 The following screen will then appear. Click **Finish** to complete the setup.




1 Hardware Connection

Method One



Method Two




You may see the **Found New Hardware Wizard**, when the adapter is plugged. Please click **Cancel**.



3 Connect to Network


(You can skip to **Appendix: Connect to Wireless Router by WPS** to quickly connect to a network if your Router or Access Point features WPS/QSS function.)

1 After installation, the configuration page will pop up on your desktop.



Note The icon  will appear on your desktop. Double-clicking on the icon can start the utility.


2 Click **Network** in the tools section to display a list of available wireless networks. Highlight the target network name (e.g. TP-LINK_Network1) and then click **Connect** to build a connection.



Note Here we only choose a wireless network with the security type of **WPA/WPA2-Personal** as an example to elaborate the following steps.


If you want to know more about the connection to a wireless network with the security type of **WPA/WPA2-Enterprise**, please refer to the User Guide on the resource CD included.

3 If the network is unsecured, you will directly connect to it. If it is security-enabled, you can input the security key into the field beside **Security Key** and then click **OK** to continue.




Note Without entering a key, you can press the WPS button on your router if the prompt **You can also connect by pushing the button on the router** appears.

4 The following screen indicates successful connectivity. Click **Close** to enjoy the Internet.




5 To view more information about the network connected, click **Status** in the tools section.




Appendix: Connect to Wireless Router by WPS

If your wireless Router features the WPS/QSS function, you can also set up a wireless connection in this way.


1 Push the **WPS/RESET** button on the back panel of the Router. Here we take Router TL-WR841ND for example.



2 With the adapter plugged into the USB port on your computer, push the **WPS** button on the adapter.



3 Wait a while for the connection progress to be completed. The following screen indicates that the connection has been successfully built. Click **OK** to finish the WPS connection.



Note For detailed instructions of WPS, please refer to the User Guide on the resource CD.

Technical Support

- For more troubleshooting help, go to www.tp-link.com/en/support/faq
- To download the latest Firmware, Driver, Utility and User Guide, go to <http://www.tp-link.com/en/support/download/>
- For all other technical support, please contact us by using the following details:

Australia / New Zealand

Tel: +61 2 8000 875465 (Depending on 1300 policy.)
Fee: Depending on rate of different carriers.
ID: support.au@tp-link.com
Service time: 24hrs, 7 days a week

Singapore

Tel: +65 6284 0493

Fee: Depending on rate of different carriers.

E-mail: support.sg@tp-link.com

Service time: 24hrs, 7 days a week

UK

Tel: +44 (0) 845 147 0017

Fee: Landline: 1p-10.5p/min, depending on the time of day. Mobile: 15p-40p/min, depending on your mobile network.

E-mail: support.uk@tp-link.com

Service time: 24hrs, 7 days a week

USA / Canada

Toll Free: +1 866 225 8139

E-mail: support.usa@tp-link.com

Service time: 24hrs, 7 days a week

Malaysia

Toll Free: 1300 88 755 465

E-mail: support.my@tp-link.com

Service time: 24hrs, 7 days a week

Ukraine

Tel: 0 800 505 508

Fee: Free for Landline; Mobile: Depending on rate of different carriers

E-mail: support.ua@tp-link.com

Service time: Monday to Friday 10:00 to 22:00

Italy

Tel: +39 023 051 9020

Fee: Depending on rate of different carriers.

E-mail: support.it@tp-link.com

Service time: Monday to Friday, 09:00 to 13:00; 14:00 to 18:00

Germany / Austria

Tel: +49 1805 875 465 (German Service)

+49 1805 TPLINK

E-mail: support.de@tp-link.com

Service time: Sunday to Friday, 09:00 to 12:00, 13:00 to 18:00 *Except public holidays

France

Tel: +33 023 051 9020

Email: support.fr@tp-link.com

Fee: 0.118 EUR/min from France

Service time: Monday to Friday, 09:00 to 18:00 *Except French Bank holidays

Indonesia

Tel: +62 1021 6386 1936

Fee: Depending on rate of different carriers.

E-mail: support.id@tp-link.com

Service time: From 9:00 to 21:00 (Moscow time)

*Except weekends and holidays in Hesse